



**Innvotech Solutions Pty Ltd**  
1/11 Crissane Road  
Heidelberg West VIC 3081  
Tel: (03) 9607-8595  
Fax: (03) 9607-8282  
www.innvotech.com.au  
info@innvotech.com.au

## **InnvoLay™ Acoustic Underlay Installation Guide**

- Never stand or store rolls on their end, always keep on a flat level surface.
- If possible roll out 24 hrs prior to cutting to allow the material to relax and acclimatise.
- Keep rolls between 18°C and 24°C or at the ambient room temperature for 2 hours prior to installation.
- All InnvoLay rolls must be installed in the same direction and allowed to relax unrolled for a minimum of 2 hours before cutting or adhering.

Preparation is the key to any successful flooring installation. Reasonable time should be spent to ensure that your subfloor is prepared well. Concrete and/or any floor type that is to be adhered to must be dry, clean, smooth, level, and free from oil, grease, fat, curing compounds, old adhesive residue, paint, wax, sealers and any extraneous materials.

If specified, then the rolls must be adhered to the sub-base using only the specified adhesive. A concrete moisture test should be carried out to make sure the floor is dry (below 5.5%) and meets the manufacturer's specifications.

Once the subfloor is prepared, establish your starting point by rolling out one InnvoLay roll vertically (long seams to go with the traffic flow where possible) and position it against the wall and/or square with the desired run configuration. Continue to roll out all the InnvoLay rolls for the entire installation that is to be adhered or laid in the one day. Lengths can be trimmed in position as required once they have had time to relax. All seams are to be butt-jointed using the precision cut factory edges.

To apply adhesive fold the first sheet to be glued in half length-ways. Apply the adhesive as per the manufacturer's specifications. Carefully roll the sheet back down onto the wet adhesive ensuring that no air is trapped underneath the InnvoLay roll. Immediately ensure proper contact with the adhesive by rolling the floor with a flooring roller. Next roll back the other half of the first sheet and half of the adjoining sheet and apply adhesive. Continue repeating the rolling in of the sheet and application of the adhesive as previous and for the remaining area.

**Disclaimer:** The installation guidelines contained herein are given to the best of our knowledge. It is impossible to foresee all site variations that may arise therefore professional construction advice should be sought in areas that are not covered in this installation guide. Application, use and interpretation of these guidelines are beyond our control and thus full installation responsibility falls exclusively with the installer. Should we nonetheless be liable for damages for any reason whatsoever, the scope of the liability shall be specifically limited to the original product cost only.